

## LLR-BAC BACnet MS/TP Light Level and Occupancy Sensor

The LLR-BAC sensors are designed to measure Light Level (LUX) in the room spaces and have built-in BACnet MS/TP communication interface. The sensors can be also used for occupancy detection.

The LLR-BAC sensors have linear 0..10V signals outputs relating to light level and optional temperature. The LLR-VBAC sensors have two 24Vac triacs (digital outputs) that can be used for the occupancy detection, or the detection is carried out through the communication network. The LLR-BAC include a built-in resistive and two digital inputs for integrating local measurements such as window contacts or external temperature sensors.

The LLR -BAC sensors can be installed on a wall surface or on a wall mounting box in dry indoor environment. The LLR-BAC sensors come with a number of additional options such as display, and one or two push buttons. Furthermore passive sensor element options are available.

The LLR-BAC sensors can also operate as temperature and light level controllers.




Model Type	Model	Description
	<b>LLR-BAC</b>	LLR BACnet MS/TP Room Light Level and Occupancy Sensors, 2 DI, 1RI, 3AO (0..10Vdc), 2DO
	<b>-LCD</b>	Display and Alarm Indication Option
	<b>-PB</b>	Push Button Interface Option with Timer
	<b>-PB2</b>	2 Momentary Push Buttons with Timer
	<b>-TE</b>	Active Temperature Sensor Option
	<b>-TE-NTC10K3</b>	Passive Temperature Sensor Option <small>See Note 1</small>

Accessories	Model	Description
	<b>SW-DCT-USB</b>	Windows Device Configuration Tool Software with Serial USB Interface, 1.8m USB Lead

**Note 1: Replaces digital input 2.**

### Order Codes

LLR - BAC - LCD - PB




e.g. LLT-BAC-LCD-PB  
 Room Light Level Sensor with BACnet,  
 Display, Push Button  
 Optional Add On  
 Optional Add On  
 Optional Add On  
 BACnet MS/TP Communication  
 Room Space Installation  
 Light Level and Occupancy (Primary Measurement)

### Technical Data

Power Supply	Power supply	24Vac/dc -10%/+15%, max 1VA
Displays and Interfaces	Option -LCD	LCD Display for Showing Light Level, Temperature and Alarm Condition using Backlight (configurable through the tool or via Network)

	Option -PB	Push Button with Delay Timer; status available through DO1, DO2 or via Network
	Option -PB2	2 x Push Buttons with Delay Timer; status available through DO1, DO2 or via Network
Signal Outputs	Analogue Outputs	3 x 0..10Vdc < 5mA; 100k min impedance for 1% accuracy
	Digital Outputs	2 x 24Vac Triacs; 2A maximum; requires 24Vac Power Supply (DO1 & DO2)
	Option -PB (Push Button)	Uses DO1 or DO2; 24Vac Triac
Signal Inputs	Resistive Input	1 x NTC10/Resistive Input, 0..50kOhms (network value)
	Digital Inputs	2 x Digital Input, Volt-Free Contact, Impedance <1KOhm Pulse Counting: Max 25Hz, Min Pulse Length 20mA (Volatile)
Sensing Characteristics	Light Level and Occupancy	
	Range	0..3,000 Lux
	Occupancy	Infrared Detection (Adjustable Delay)
	Temperature (TE-option)	
	Range	0..50°C (32..122°F)
	Accuracy	±0.3°C
Communication	BACnet Communications	
	Protocol	BACnet MS/TP
	Interface	RS485; maximum 63 devices
	MAC Addressing	0..63 via a bit switch; 0..247 via tool / network
	Communication	9k6/19k2/38k4/76k8 Baud; Parity None/Even/Odd, 1 or 2 Stop Bits (baud rate adjustable through bit switch)
Connections	Terminal Connections	Solid and Stranded Cable; 55° Angle for Wiring Maximum Size: 0.05 to 1.5mm <sup>2</sup> (EN ISO) / 14 to 30 AWG (UL) Rising Clamp: Size 2.5 x 1.9mm
Environmental Conditions	Operating	
	Temperature	0°C...+50°C (32..122°F)
	Humidity	0...95%rh (non-cond.)
	Storage	
	Temperature	-30°C...+70°C (-22..158°F)
	Humidity	0...95%rh (non-cond.)
Standards	CE Conformity	CE Directive 2004/108/EY EN61000-6-3: 2001 (Generic Emission) EN61000-6-1: 2001 (Generic Immunity).
	Degree of Protection	IP20
Housing	Housing Material	ABS Plastics, Self Extinguishing
	Mounting	Wall or Junction Box Mounting, RAL9010 Pure White Ceiling Mounting
	Dimensions	W86 x H120 x D29mm
	Weight	180g

**Wiring Terminals**



\* Each of the outputs can be configured individually as for temperature, light level, control or as a network value.

DO1	Digital Output; 24Vac Triac Switching to 0V; max. 2A (default Push Button Status)
DO2	Digital Output; 24Vac Triac Switching to 0V; max. 2A (default Occupancy status)
G	24Vac/dc Power Supply
G0	0V Common
Y1	0..10Vdc Analogue Output (Temperature)
Y2	0..10Vdc Analogue Output (LUX)
Y3	0..10Vdc Analogue Output (Function Selectable)
G0	0V Common
A+	RS485 A+ Connection (BACnet MS/TP)
B-	RS485 B- Connection (BACnet MS/TP)
G0	0V Common
RI1	- (Not Applicable)
DI1	Digital Input; Volt-Free, Max 25Hz, Min Pulse Length 20mS
RI2	NTC10/Resistive Input 0..50kOhms
DI2	Digital Input; Volt-Free, Max 25Hz, Min Pulse Length 20mS

**Wiring Precautions**

Switch off the power before any wiring is carried out. If the sensor has the LCD display fitted, unplug the LCD display and then wire the power supply and analogue outputs, if relevant.

After the wiring has been completed; plug-in the display and power up the sensor.

**Digital Input Pulse Counting**

Digital Inputs can be used for pulse counting up to 25Hz, minimum pulse length 20mS. The pulse count is stored in a dedicated register and can be read over the network. It is possible to write to this register to reset the value.

**NOTE: The pulse count value is not battery backed, and therefore the network master is required to manage the data synchronisation in case of power failure.**

**NTC10/ Resistive Input**

The resistive input can be configured to operate as a NCT10 input or a Resistive Input. As default the inputs are configured as NTC10. The maximum measurement range is -10°C to 100°C (-40°F to 212°F). The configuration is changed via the Configuration Software.

**Y1/Y2/Y3 Analogue Output Operation (Modes)**

The analogue outputs Y1/Y2/Y3 can be configured for the following options.

Output Modes	Description
Network	The output is set by the network (BACnet).
Temperature Measurement (Default for Y1)	The output represents the temperature measurement. This is scaled over 0..10V.
Light Measurement (default for Y2)	The output represents the light level measurement. This is scaled over 0..10V.
Temperature Control	The output represents the temperature control signal.
Light Control (requires -LL option)	The output represents the light level (LUX) control signal.

**DO1/DO2 Digital Output Operation**


The DO2 is used to switch output on when occupancy is detected. If the push button option (-PB) is fitted then DO1 is set to switch ON when push button is pressed (delayed switch off) The outputs are also configurable to other functions as listed below.

Digital Output Mode Options	Description (Typical Operation)
Network	The DO1/DO2 is switched on over the communication network
Temperature Control Mode (e.g. Low Temperature Limit)	Reverse Mode: The DO1/DO2 is switched ON when the temperature drops below the Temperature Setpoint - Temperature Mode Hysteresis. The output is switched OFF when the temperature exceeds the Setpoint. The control direction is adjustable; reverse (heating) / direct (cooling).
Light Level Control (LUX) Mode (e.g. Low Light Level)	Reverse Mode: The DO1/DO2 is switched ON when the light level drops below the Light Level Setpoint - Light Level Digital Output Mode Hysteresis, and switches OFF when the level increases above Setpoint. The control direction is adjustable.
Occupancy)	The DO1/DO2 is switched ON when the occupancy sensor detects occupancy; the output remains on adjustable time "Occupancy Delay Time Setting" plus approx 10 seconds after occupancy has been detected.
Push Button	If -PB option is fitted, it is possible to have the DO1 (or DO2) on for the "Push Button Delay Time" specified in the settings after the pressing of button is detected.

**Light Level Measurement Output Scaling**


The LLR sensors measure the light level. The light level (LUX) reading is available over the BACnet network, and the measurement can be sent to any of the analogue outputs (Y1/Y2/Y3).

This output is scaled as default 0% = 0 LUX and 100% = 3,000 LUX). The scaling can be modified through Maximum LUX Scaling parameter.




**Occupancy Sensor**

The LLR offers a low power Passive Infrared Motion sensor with 21mm Fresnel lens designed for HVAC ventilation and lighting control applications. The sensor detects human body within its detection range. The LLR sensor employs a dual element pyroelectric infrared sensor with advanced electronics circuitry. The occupancy status is available over the network or via the digital output.




Occupancy Sensor in Ceiling Mounting



**Light Level (LUX) Control Loop Operation**

**Proportional Control (Reverse/ Direct)**

The LUX measurement can also be used for the light control. The calculated control demand is sent to the output Y1, Y2 or Y3 (depending on the corresponding analogue output mode selection).




The light control loop output corresponds to the light level setpoint and the light control proportional band. If configured as Reverse Control, then if the light level drops below the setpoint the loop output starts to modulate to 100%. When the light level is the amount of the Proportional Band below the setpoint the loop output is 100%. In the Direct Control mode the output modulates in reverse. The configuration is done via the configuration parameters with the DCT tool.

The LUX control loop can also be configured to operate as Proportional + Integral control by changing the Integral Action Time from 0 to a required value.

It is possible apply the Boost function to the control loop to override the output to 100% (see Boost Function for more details).

**Temperature Measurement Output Scaling and Single Point Calibration (TE-Option)**

If TE-option is fitted the LLR can also measure the room space temperature, and the measurement can be sent to any of the analogue outputs (Y1/Y2/Y3). It is also available over Modbus.




This output is scaled as default 0% = 0°C and 100% = 50°C). The scaling can be modified through Maximum Temperature Scaling parameter. The output can also be scaled in Fahrenheit units.

Furthermore the temperature measurement reading can be adjusted on site using the Single Point Calibration field.

**Temperature Control Loop Operation (TE-Option)**

**Proportional or PI Control (Reverse/ Direct)**

The temperature measurement can also be used for the temperature control. The calculated control demand is then send to the output Y1, Y2 or Y3 (depending on the corresponding analogue output mode selection).



The temperature control loop output corresponds to the temperature setpoint and the temperature proportional band. If configured as Reverse Control (heating), then if the temperature level drops below the setpoint the loop output starts to modulate to 100%. When the temperature is the amount of the Proportional Band below the setpoint

the loop output is 100%. In the Direct Control mode the output modulates in reverse. The configuration is done via the configuration parameters using DCT Tool.

The temperature control loop can also be configured to operate as Proportional + Integral control by changing the Integral Action Time from 0 to a required value.

It is possible apply the Boost function to the control loop to override the output to 100% (see Boost Function for more details).

**Boost Function**

It is possible to boost/override the control output to 100%. This can be achieved via a push button on the device (PB-options) or via a digital input. If the Push Button is used then the control output is boosted to 100% for the amount of Push Button Delay Time. When the boost is active the Blue Push Button backlight is lit. The boost can be cancelled by pressing the push button again.

When the digital input option is selected, the output is boosted to 100% when the input is closed. When the digital input is opened the output remains 100% for the time set in the parameter Digital Input Off Delay.

**Push Buttons**

It is possible to fit up to four push buttons (or up to two if -SPB push button setpoint option is fitted). The push buttons can be used to activate the boost as described in Boost Function section, or used as a network user interface. The push button LED is as default controlled by the internal application i.e. the LED is ON when the push button timer is active.


If the Push Button LED Mode is set to BMS, then the LED can be controlled by the BMS. In typical application, when the user presses the push button, the internal timer starts, and the BMS reads the push button status. When the push button status has been confirmed by the BMS, the BMS switches the corresponding PB LED ON and therefore sending acknowledgement to the user. It is not possible to reset the push button timer in network mode by pressing the button again.

Note: If -SPB option is fitted Push Button 1 and Push Button 2 become as setpoint adjustment buttons. PB option activates Push Button 3 and PB2 option activates Push Button 3 and 4.

Note: It is possible to print the push button caps with custom legends. Please contact SyxtSense Sales for further details.


**Digital Output DO1/DO2 Control Modes**

The digital outputs DO1/DO2 can also be configured to work in LUX or temperature control modes (instead of as an occupancy measurement). In these modes the corresponding digital output is switched ON/OFF based on the corresponding Setpoint property and the corresponding hysteresis. The direction of the operation is also adjustable through Control Loop Operating Mode Parameter. The diagram below illustrates the operation for Temperature Control Mode. The same concept is applicable for the LUX control mode.



**Display (Requires Option -LCD)**

The LCD display shows the temperature and LUX readings. These readings can be rotated. The display has white backlight which is as default switched off. The backlight can be switched on and its intensity can be adjusted via the configuration tool.




**Note: The backlight is permanently on if activated. At 50% intensity the backlight lifetime is approx 10,000 hours. After this time the LCD module needs replacing if the backlight is required. The display continues to operate without the backlight.**

**Alarm Indication with -LCD Option**

The sensor can be configured to monitor the temperature or light levels for alarms. The alarm condition is displayed using the backlight colours of the LCD. If the measurement exceeds the amber alarm limit then the amber backlight is switched ON. If the measurement exceeds the red alarm limit, the red backlight is switched ON. At normal condition no backlight is ON (can be configured to be white backlight in normal mode - note the maximum life of 10,000 hours of the backlight). The alarm mode has an adjustable hysteresis to prevent the backlight flickering and all alarm limits are adjustable.

**Configuration Parameters and Programming**


The parameter options can be configured using the DCT Sensor Configuration Tool software. If the DCT Configuration software is used, this is connected via the PC USB cable to the programming header of the transmitter as shown on the image below.



The correct process for connecting the sensor via the USB is as follows:-

- Disconnect USB Connector from PC
- Disconnect the Sensor from Power
- Plug-In the 4-Way Connector to the Sensor
- Connect the USB to the PC
- Power Up the Sensor

**NOTE: Always disconnect USB from PC before plugging the cable into the sensor.**



Common Parameters	
Parameter Name	Description
Defaults	Reloads the default configuration from the sensor non-volatile memory. <b>Note: All modified settings are lost.</b>
Reset	Performs soft reset of the sensor. Apply after major changes.
Read	Reads the sensor data.
Write	Writes the new settings to the sensor (automatically stored in the non-volatile memory)

Common Parameters	
Parameter Name	Description
COM Port	Select the COM port for the USB Cable. USB cable driver must be installed in order the Serial to TTL connection to operate.

Live IO-View		
Parameter Name	Description	Range

**INPUTS**

Temperature Sensor	Temperature Sensor Reading	0..50°C (32..122°F)
LUX Sensor	LUX Sensor Reading	0..3,000 LUX
Resistive Input 2	Resistive Input 2 Reading	0..50kOhms
Digital Input 1	Digital Input 1 Status	Off - On
Digital Input 2	Digital Input 2 Status	Off - On
Occupancy	Occupancy Status	Off - On
Push Button	Push Button Status	Off - On
Configuration Switch	Bit Switch Status for Each Switch	00000000 - 11111111

**OUTPUTS**

Triac 1	Digital Output 1	Off - On
Triac 2	Digital Output 2	Off - On
Analogue Output 1	Analogue Output 1	0..100%
Analogue Output 2	Analogue Output 2	0..100%
Analogue Output 3	Analogue Output 3	0..100%

Control Parameters		
Parameter Name	Description	Range

**TEMPERATURE**

Temperature Loop Operating Mode	Direction of the temperature control loop.	0 = Reverse Control (Heating) 1 = Direct Control (Cooling)
Temperature Control Setpoint	Temperature Setpoint	0.0...150.0°C/°F (Default 20°C)
Temperature Proportional Band	Temperature Proportional Band	1.0...150.0°C/°F (Default 50°C)
Temperature Control Integral Action	Integral Action time of the temperature control loop. Set to 0 to disable.	0..10,000 seconds (Default 0s)
Temperature Digital Output Mode Hysteresis	Hysteresis for the digital output temperature control function.	0.1...150.0°C/°F (Default 2°C)
Temperature Loop Boost Input	Boosts the Control Output to 100%	Select Push Button 1/2 or Digital Input 1/2.

**HUMIDITY (Not Applicable)****CO2 (Not Applicable)****LUX**

Lux Loop Operating Mode	Direction of the LUX control loop.	0 = Reverse Control 1 = Direct Control
Lux Control Setpoint	LUX Setpoint	0..3,000 Lux (Default 400 Lux)
LUX Proportional Band	LUX Proportional Band	1..3,000 Lux (Default 400 Lux)
LUX Control Integral Action	Integral Action time of the LUX control loop. Set to 0 to disable.	0..10,000 seconds (Default 0s)
LUX Digital Output Mode Hysteresis	Hysteresis for the digital output LUX control function.	1..3,000 Lux (Default 100 Lux)
LUX Loop Boost Input	Boosts the Control Output to 100%	Select Push Button 1/2 or Digital Input 1/2.

**SETPOINT ADJUST**

Setpoint Adjuster Minimum Value	Sets the minimum value for the setpoint (setpoint turned fully anti clockwise)	-500..0 (Default -3.0)
Setpoint Adjuster Maximum Value	Sets the maximum value for the setpoint (setpoint turned fully clockwise)	0..500 (Default 3.0)
Setpoint Value Influence to Control Setpoint	Setpoint Value Influence to Control Setpoint	0 = No Influence 1 = CO2 Control (not applicable) 2 = Temperature 3 = Humidity (not applicable) 4 = Lux



<b>Control Parameters</b>		
<b>Parameter Name</b>	<b>Description</b>	<b>Range</b>
Save SPA	Saves User Setpoint (Setpoint Adjustment) changes to non-volatile after changes have been completed.	0 = Disabled (Default) 1 = Enabled
Reset SPA on SP Change	Resets the User Setpoint Adjustment (SPA), when the setpoint is written over the network.	0 = Disabled 1 = Enabled (Default)

<b>Inputs / Outputs</b>		
<b>Parameter Name</b>	<b>Description</b>	<b>Range</b>
<b>SENSOR INPUTS</b>		
Temperature Offset	One Point Temperature Calibration Field	-3.0..+3.0°C/°K (Default 0°C)
Temperature AO Scale	Analogue Output Maximum Temperature Scaling	0.1...150.0°C/°F (Default 50°C)
LUX AO Scale	Analogue Output Maximum Lux Scaling	1000..3,000 Lux (Default 3,000 Lux)
Occupancy Off Delay	Delay Time Setting for Occupancy	1..7200 Seconds (Default 600s)
Push Button Off Delay	Delay Time Setting for Push Button	1..28800 Seconds (Default 600s)
Push Button Mode	Push Button LED Mode (Fw2.21)	0 = Local (default) 1 = BMS
DI1 Off Delay	Delay Time Setting for Digital Input 1	0..28800 Seconds (Default 0s)
DI2 Off Delay	Delay Time Setting for Digital Input 2	0..28800 Seconds (Default 0s)

**OUTPUTS**

AO1 (Y1)	Analogue Output Y1 Mode	0 = Network Value 1 = CO2 (not applicable) 2 = Temperature Measurement 3 = Humidity (not applicable) 4 = Light Measurement (LUX) 5 = CO2 Control (not applicable) 6 = Temperature Control 7 = Humidity Cont (not applicable) 8 = Light Control (LUX) 9 = Maximum (not applicable) 10 = Potentiometer
AO2 (Y2)	Analogue Output Y2 Mode	0 = Network Value 1 = CO2 (not applicable) 2 = Temperature Measurement 3 = Humidity (not applicable) 4 = Light Measurement (LUX) 5 = CO2 Control (not applicable) 6 = Temperature Control 7 = Humidity Cont (not applicable) 8 = Light Control (LUX) 9 = Maximum (not applicable) 10 = Potentiometer
AO3 (Y3)	Analogue Output Y3 Mode	0 = Network Value 1 = CO2 (not applicable) 2 = Temperature Measurement 3 = Humidity (not applicable) 4 = Light Measurement (LUX) 5 = CO2 Control (not applicable) 6 = Temperature Control 7 = Humidity Cont (not applicable) 8 = Light Control (LUX) 9 = Maximum (not applicable) 10 = Potentiometer
DO1	Digital Output 1 Mode	0 = Network Value (Default) 1 = CO2 Relay (not applicable) 2 = Temperature Relay 3 = Humidity Relay (not applicable) 4 = Light Relay (LUX) 5 = Occupancy Relay 6 = Push Button

Inputs / Outputs		
Parameter Name	Description	Range
DO2	Digital Output 2 Mode	0 = Network Value (Default) 1 = CO2 Relay (not applicable) 2 = Temperature Relay 3 = Humidity Relay (not applicable) 4 = Light Relay (LUX) 5 = Occupancy Relay 6 = Push Button

Alarm/Display/Comms		
Parameter Name	Description	Range
<b>ALARMS</b>		
Alarm Source	Alarm LED Mode	0 = Not Applicable (CO2) 1 = Temperature 2 = Not Applicable (Humidity) 3 = LUX 4 = None
Alarm Amber Threshold	Amber Alarm LED Switching Point	0..5000 (Default 750)
Alarm Red Threshold	Red Alarm LED Switching Point	0..5000 (Default 1250)
Alarm Hysteresis	Alarm LED Hysteresis	0..5000 (Default 50)

DISPLAY		
Temperature Units	Temperature Unit Selection	0 = Celsius 1 = Fahrenheit
Display Mode	Display Mode	0 = Rotate Installed 1 = CO2 Only (not applicable) 2 = Temperature Only 3 = LUX Only 4 = Setpoint Only
LCD brightness	Brightness of the LCD	Off - 10% to 100%

COMMS		
BACnet Baud Rate	BACnet Baud Rate (can only be set if BR1 and BR2 are in OFF position)	0 = 9600 (Default) 1 = 19200 2 = 38400 3 = 57600
BACnet Parity	BACnet Parity	0 = None (Default) 1 = Odd 2 = Even
Stop Bits	Stop Bits	0 = 1 Stop Bit (Default) 1 = 2 Stop Bits
Address	BACnet Address (can only be set if all address bit switches are in OFF position)	0..247 (Default 1)


**Parameter Storage**

The configuration parameters are stored in the non-volatile memory. The DCT (Device Configuration Tool) software will automatically store the register values on the non-volatile permanent memory after the changes are carried out. If the changes are carried out over the BACnet network using Proprietary BACnet properties, then "NonVol Update" flag is required to be forced on to save the changes. The parameter returns automatically to the off state once the values have been stored.

**Setting Up BACnet Address and Baud Rate**

The LLR-MOD BACnet address and the baud rate is normally set through the bit switch. It is also possible to set the address and baud rate over the configuration tool.

**NOTE: The new settings are activated automatically after approx 5 seconds if the bit switch positions have not been moved. In this case the controller reset is applied to activate the new settings.**



**BACnet Interoperability  
Building Blocks Supported  
(Annex K)**

Application Service	Initiate	Execute	BIBB
ReadProperty		Yes	DS-RP-B
ReadPropertyMultiple		Yes	DS-RPM-B
WriteProperty		Yes	DS-WP-B
ReinitializeDevice		Yes	
Who-Is		Yes	DM-DDB-B
I-Am	Yes		
Who-Has		Yes	DM-DOB-B
I-Have	Yes		
DeviceCommunicationControl		Yes	DM-DCC-B

**BACnet Standard Object  
Types Supported**

No dynamic Creation or Deletion supported. Objects, and object instances, are assigned to fixed functions within the proprietary control application of the product as follows:

Object	Number Of Instances	Instance Assignments
Device Object	1	
Analog Input	7	AI(0) – Temperature Sensor AI(1) – Setpoint Adjust AI(2) – Not Assigned AI(3) – Not Assigned AI(4) – RI2 AI(5) – Not Assigned AI(6) – LUX Sensor
Analog Outputs	3	AO(0) – Y1 Output AO(1) – Y2 Output AO(2) – Y3 Output
Analogue Value	7	AV(0) – Temperature Setpoint AV(1) – Not Assigned AV(2) – Not Assigned AV(3) – LUX Setpoint AV(4) – DI1 Pulse Count AV(5) – DI2 Pulse Count AV(7) - LCD Backlight Brightness
Binary Input	7	BI(0) – DI1 input BI(1) – DI2 Input BI(2) – Occupancy BI(3) – Push Button 1 BI(4) - Push Button 2 BI(5) - Push Button 3 BI(6) - Push Button 4
Binary Output	7	BO(0) – DO1 Output BO(1) – DO2 Output BO(2) - SPA Reset BO(3) - PB1_LED BO(4) - PB2_LED BO(5) - PB3_LED BO(6) - PB4_LED

**Device Object Properties  
(Required Object Properties)**

Property Name /ID	Attributes	Range	Default
Object Identifier	R/W		MAC_Address + 651000 (Adjustable)
Object Name	R/W	32 Characters Max	Concatenation of product type and MAC address i.e. "LLR_001"
Object Type	R		8
System Status	R		STATUS_OPERATIONAL
Vendor Name	R		SyxthSense
Vendor Identifier			651

Property Name /ID	Attributes	Range	Default
Model Name	R		URD
Protocol Version	R		1
Protocol Revision	R		10
Max APDU Length	R		480
Segmentation Support	R		No
APDU Timeout	R		3000 ms
Number APDU Retries	R		3
MaxMaster	R		127
Max_Info_Frames	R		1
Database Revision	R		0

### Analogue Input Objects

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		AI(0) – Temperature Sensor AI(1) – Setpoint Adjust AI(2) – Not Assigned AI(3) – Not Assigned AI(4) – RI2 AI(5) – Not Assigned AI(6) – LUX Sensor
	Object Type	R		0
	Present Value	R/W	AI(0): 0..150 AI(1): -500 ..500 AI(2): Not Assigned AI(3): Not Assigned AI(4): 0..50000 AI(5): Not Assigned AI(6): 0..3000	
	Status Flag	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Units	R		AI(0): UNITS_DEGREES_CELCIUS or UNITS_DEGREES_FAHRENHEIT AI(1): UNITS_DEGREES_CELCIUS or UNITS_DEGREES_FAHRENHEIT AI(2): Not Assigned AI(3): Not Assigned AI(4): UNITS_OHMS AI(5): Not Assigned AI(6): UNITS_LUXES
	<b>Optional Properties</b>	None		
<b>Proprietary Properties</b>	None			

### Analogue Output Objects

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		AO(0) = "Y1" AO(1) = "Y2" AO(2) = "Y3"
	Object Type	R		1
	Present Value	R/W	0..100	
	Status Flag	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Units	R		UNITS_PERCENT

	Property Name /ID	Attributes	Range	Default
<b>Optional Properties</b>	None			
<b>Proprietary Properties</b>	None			

#### Analogue Value Objects

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		AV(0) – Temperature Setpoint AV(1) – Not Assigned AV(2) – Not Assigned AV(3) – LUX Setpoint AV(4) - DI1 Pulse Count AV(5) - DI2 Pulse Count AV(6) - LCD Backlight Brightness
	Object Type	R		2
	Present Value	R/W	AV(0): 0..150 AV(1): N/A AV(2): N/A AV(3): 0..3000 AV(4): 0..4278190080 AV(5): 0..4278190080 AV(6): 0..10	
	Status Flag	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Units	R		AV(0) = UNITS_DEGREES_CELSIUS or UNITS_DEGREES_FAHRENHEIT AV(1) = Not Assigned AV(2) = Not Assigned AV(3) = UNITS_LUXES AV(4) = NO_UNITS AV(5) = NO_UNITS AV(6) = NO_UNITS
	Priority Array	R		
	Relinquish Default	R/W		AV(0) = Nonvol Temperature Setpoint AV(1) = Not Assigned AV(2) = Nonvol CO2 Setpoint AV(3) = Nonvol LUX Setpoint AV(4) = 0 AV(5) = 0 AV(6) = 0
<b>Optional Properties</b>	None			
<b>Proprietary Properties</b>	None			

## Binary Input Objects

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		BI(0) = "DI1" BI(1) = "DI2" BI(2) = "Occupancy" BI(3) = "Push Button 1" BI(4) = "Push Button 2" BI(5) = "Push Button 3" = PB Option when SPB fitted BI(6) = "Push Button 4" = PB2 Option Second Button when SPB fitted
	Object Type	R		3
	Present Value	R/W	0..1	
	Status Flags	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Polarity	R/W		POLARITY_NORMAL
	Active Text	R		"on"
Inactive Text	R		"off"	
<b>Optional Properties</b>	None			
<b>Proprietary Properties</b>	None			

## Binary Output Objects

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		BO(0) = "DO1" BO(1) = "DO2" BO(2) = "SPA Reset" <sup>*1</sup> BO(3) = "PB1_LED" <sup>2*</sup> BO(4) = "PB2_LED" <sup>2*</sup> BO(5) = "PB3_LED" <sup>2*</sup> BO(6) = "PB4_LED" <sup>2*</sup>
	Object Type	R		4
	Present Value	R/W	0..1	
	Status Flags	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Polarity	R/W		POLARITY_NORMAL
	Priority Array	R		
	Relinquish Default	R/W		BINARY_INACTIVE
	Active Text	R		"on"
Inactive Text	R		"off"	
<b>Optional Properties</b>	None			
<b>Proprietary Properties</b>	None			

Note 1: Setting "SPA Reset" to true, disables the user setpoint adjustment.

Note 2: Set "Push Button Mode" to BMS in order to be able to control push button LEDs. When PBx\_LED is set to 'off' the Push Button timer is reset. PBx\_LED has to be set to 'null' in order to be able to re-trigger the push button.password

**Multi-State Input Objects**

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		
	Object Name	R		"Alarm Level"
	Object Type	R		13
	Present Value	R/W	1,2,3 (Green, Amber, Red)	
	Status Flags	R		
	Event State	R		
	Out-Of-Service	R/W		FALSE
	Number-Of-States	R		3
<b>Optional Properties</b>	None			
<b>Proprietary Properties</b>	None			

**Proprietary Object Types** No dynamic Creation or Deletion supported

Object	Number Of Instances	Instance Assignments
Application Configuration Object	1	Provides a container for all the proprietary application specific properties.

**App\_Config Object**

	Property Name /ID	Attributes	Range	Default
<b>Required Object Properties</b>	Object Identifier	R		MAC_Address + 651000
	Object Name	R		"App_Config"
	Object Type	R		128
<b>Optional Properties</b>	None			

	Property ID	Description	BACnet Data Type	Range
<b>Proprietary Properties</b>	30100	Firmware Version	Unsigned	Read Only
	40004	Analogue Output Y1 Mode	Unsigned	0 = Network Value 1 = Not Applicable (CO2) 2 = Temperature Measurement 3 = Not Applicable (Humidity) 4 = Light Measurement 5 = Not Applicable (CO2 Control) 6 = Temperature Control 7 = Not Applicable (Humidity) 8 = Light Control 9 = Not Applicable (Maximum Control)
	40005	Analogue Output Y2 Mode	Unsigned	0 = Network Value 1 = Not Applicable (CO2) 2 = Temperature Measurement 3 = Not Applicable (Humidity) 4 = Light Measurement 5 = Not Applicable (CO2 Control) 6 = Temperature Control 7 = Not Applicable (Humidity) 8 = Light Control 9 = Not Applicable (Maximum Control)

40006	Analogue Output Y3 Mode	Unsigned	0 = Network Value 1 = Not Applicable (CO2) 2 = Temperature Measurement 3 = Not Applicable (Humidity) 4 = Light Measurement 5 = Not Applicable (CO2 Control) 6 = Temperature Control 7 = Not Applicable (Humidity) 8 = Light Control 9 = Not Applicable (Maximum Control)
40008	Digital Output 1 Mode	Unsigned	0 = Network Value (Default) 1 = Not Applicable (CO2) 2 = Temperature Relay 3 = Not Applicable (Humidity) 4 = Light Relay 5 = Occupancy Relay 6 = Push Button
40009	Digital Output 2 Mode	Unsigned	0 = Network Value (Default) 1 = Not Applicable (CO2) 2 = Temperature Relay 3 = Not Applicable (Humidity) 4 = Light Relay 5 = Occupancy Relay 6 = Push Button
40015	Temperature Control Setpoint	Unsigned	0.0...150.0°C/°F (Default 20°C)
40016	Temperature Proportional Band	Unsigned	0.1...150.0°C/°F (Default 50°C)
40017	Temperature Control Integral Action	Unsigned	0..10,000 seconds
40018	Temperature Loop Operating Mode	Unsigned	0 = Reverse Control (Heating) 1 = Direct Control (Cooling)
40019	Temperature Digital Output Mode Hysteresis	Unsigned	0.1...150.0°C/°F (Default 2°C)
40025	Lux Control Setpoint	Unsigned	0..3,000 Lux (Default 400 Lux)
40026	LUX Proportional Band	Unsigned	1..3,000 Lux (Default 400 Lux)
40027	LUX Control Integral Action	Unsigned	0..10,000 seconds
40028	Lux Loop Operating Mode	Unsigned	0 = Reverse Control 1 = Direct Control
40029	LUX Digital Output Mode Hysteresis	Unsigned	1..3,000 Lux (Default 100 Lux)
40030	Amber Alarm LED Switching Point	Unsigned	0..5000 (Default 750)
40031	Red Alarm LED Switching Point	Unsigned	0..5000 (Default 1250)
40032	Alarm LED Hysteresis	Unsigned	0..5000 (Default 50)
40033	Alarm LED Mode	Unsigned	0 = Not Applicable 1 = Temperature 2 = Not Applicable 3 = LUX
40034	Delay Time Setting for Occupancy	Unsigned	1..7200 Seconds



40035	Delay Time Setting for Push Button	Unsigned	1..28800 Seconds
40036	Setpoint Adjuster / Potentiometer Low Position	REAL	-500.0..0 (-3.0) Default
40037	Setpoint Adjuster / Potentiometer High Position	REAL	0..+500.0 (3.0) Default
40038	Setpoint Value Influence to Control Setpoint	Unsigned	0 = No Influence 1 = Not Applicable (CO2) 2 = Temperature 3 = Humidity 4 = Lux
40039	Temperature Unit Selection	Unsigned	0 = Celsius 1 = Fahrenheit
40041	Display Mode	Unsigned	0 = Rotate Installed 1 = Not Applicable (CO2 Only) 2 = Temperature Only 3 = LUX Only
40043	Analogue Output Maximum Temperature Scaling	Unsigned	0.1...150.0°C/°F (Default 50°C)
40045	Analogue Output Maximum Lux Scaling	Unsigned	1000..3,000 Lux (Default 3,000 Lux)
40047	One Point Temperature Calibration Field	REAL	-3.0..+3.0°C/°K (Default 0°C)
40050	MAC Address	Unsigned	0..255
40051	Baud Rate	Unsigned	0 = 9600 (Default) 1 = 19200 2 = 38400 3 = 57600
40067	Hold On Delay Setting for Digital Input 1	Unsigned	1..28800 Seconds
40068	Hold On Delay Setting for Digital Input 2	Unsigned	1..28800 Seconds
40100	Force Reset	Unsigned	0 = Normal 1 = Force Reset
40101	Non Volatile Memory Update	Unsigned	0 = Normal 1 = Update
40103	Force Factory Defaults	Unsigned	0 = Normal 1 = Force Defaults
40104	Force 0..10V Output Calibration Routine	Unsigned	0 = Normal 1 = Force Calibration

**Dimensions**

